

INTRODUCTION

AKSA POWER GENERATION

Aksa power generation system, providing optimum performance, and reliability, for stationary standby, prime power, and continuous duty applications. All generator sets are factory build, and production tested.

Power (kVA)

3 Phase, 50 Hz, PF 0.8

Voltage	STANDBY RATING (ESP)	PRIME RATING (F	PRP)	Standby Amper
Voltage	kW	kVA	kW	kVA	
400/231	1320,00	1650,00	1200,00	1500,00	2381,64

STANDBY RATING (ESP) Applicable for supplying power to varying electrical load for the duration of power interruption of a reliable utility source. ESP is in accordance with ISO 8528-1. Overload is not allowed.

PRIME RATING (PRP) Applicable for supplying power to varying electrical load for unlimited hours. PRP is in accordance with ISO 8528-1. 10 % overload capability is available for a period of 1 hour within 12-hour period of operation.

General Characteristics

Model Name	APD 1650 M
Frequency (Hz)	50
Fuel Type	Diesel
Engine Made and Model	MITSUBISHI S12R-PTAA2
Alternator Made and Model	ECO 46-1S/4 A
Control Panel Model	DSE 7320
Canopy	AK 99 - External Removable Silencer

ENGINE SPECIFICATIONS

ENGINE SPECIFICATIONS	
Engine	MITSUBISHI
Engine Model	S12R-PTAA2
Number of Cylinder (L)	12 cylinders - V type
Bore (mm.)	170
Stroke (mm.)	180
Displacement (lt.)	49.03
Aspiration	Turbo Charged and AfterCooled
Compression Ratio	13.5:1
RPM (d/dk)	1500
Oil Capacity (Total With Filter) (It)	180
Standby Power (kW/HP)	1441/1932
Prime Power	1314/1761
Block Heater QTY	2
Block Heater Power (Watt)	3000
Fuel Type	Diesel
Injection Type and System	Direct
Type of Fuel Pump	Mitsubishi PS6x2 (In-Line)
Governor System	Electronic
Operating Voltage (Vdc)	24 Vdc

AKSA POWER GENERATION

Battery and Capacity (Qty/Ah)	4x143
Charge Alternator (A)	30
Cooling Method	Water Cooled
Cooling Fan Air Flow (m3/min)	1800
Coolant Capacity (engine only / with radiator) (It)	33/317
Air Filter	Dry Type
Fuel Cons. Prime With %100 Load (lt/hr)	308
Fuel Cons. Prime With %75 Load (lt/hr)	234.2
Fuel Cons. Prime With %50 Load (lt/hr)	163.3
ALTERNATOR CHARACTERISTICS	
Manufacturer	Mecc Alte
Alternator Made and Model	ECO 46-1S/4 A
Frequency (Hz)	50
Power (kVA)	1500
Voltage (V)	400
Phase	3
A.V.R.	DER1
Voltage Regulation	(+/-)0.5%
Insulation System	Н
Protection	IP23
Rated Power Factor	0.8
WEIGHT COMP. GENERATOR (Kg)	3010
COOLING AIR (m³/min)	135
Open Gen.Set Dimensions (mm)	
LENGTH	4970
WIDTH	2212
HEIGHT	3022
DRY WEIGHT (kg.)	11400
TANK CAPACITY (It.)	2000
Gen.Set Canopy Dimensions (mm) LENGTH	9000
WIDTH	2800
HEIGHT	3307
DRY WEIGHT (kg.)	15450
TANK CAPACITY (It.)	2200
	1. Steel structure made from steel sheet and steel
	profiles. 2. Canopy and panels made from powder coated sheet steel.





- 3. Emergency stop push button.
- 4. Control panel is mounted on the baseframe located at
- the back of the Generator set.
- 5. Cables out locations are back of the canopy.
- 6. Corrosion.resistant locks and hinges.
- 7. Oil could be drained via valve and a hose.
- 8. Exhaust system on the canopy.

9. Special large access doors for easy maintanance.
 10. The cap on the canopy provides easy access to radiator cap.

11. Lifting points similar to ISO container, located on each top corner of the Canopy.

12. Sound proofing materials.

13. Fuel tank is at front of the canopy ,easy access to the fuel tank via lockable door.

14. Integrated ladder built in toside of the canopy allows access to the top of the canopy.

INTRODUCTION

Sound-attenuated and weather protective enclosures for generating sets from Aksa, meet event the sound requirements and provide optimum protection from inclement weather and development by our specialist acoustic engineers. Our modular designed sound insulated canopies provide ease of access for servicing and general maintenance and interchangeable components permitting on-site repair. Enclosures are designed to optimize genset cooling performance, providing you with confidence that genset ratings and ambient capability.

Control Panel

Control Module	DSE
Control Module Model	DSE 7320
Communication Ports	MODBUS
	 Menu navigation buttons Close mains button

- 3. Main Status and instrumentation display
- 4. Alarm LED's
- 5. Close generator button
- 6. Status LED's
- 7. Operation selecting buttons

Devices

DSE, model 7320 Auto Mains Failure control module Static battery charger Emergency stop push button and fuses for control circuits

CONSTRUCTION and FINISH

Comonents installed in sheet steel enclosure.

Phosphate chemical, pre-coating of steel provides corrosion resistant surface

Polyester composite powder topcoat forms high gloss and extremely durable finish

Lockable hinged panel door provides for easy component access

INSTALLATION

Control panel is mounted generating set baseframe on robust steel stand or power module. Located at side of generating set with properly panel visibility.

GENERATING SET CONTROL UNIT

The DSE 7320 conrol module is a standard addition to our generator sets from 220 kVA upwards and it has been designed to start and stop diesel andgas generating sets that include electronic and non electronic engines.

The DSE 7320 includes the additional capability of being able to monitor a mains (utility) supply and is therefore suitable for controlling a standby generating set in conjunction with an automatic transfer switch.

The DSE7320 also indicates operational status and fault conditions, automatically shutting down the generating set and

Manufacturer reserves the right to make change in the model, technical specifications, color, equipment, accessories and images without prior notice. (22.11.2023)

www.aksa.com.tr



STANDARD SPECIFICATIONS

Microprocessor controlled

AKSA POWER GENERATION

- 132 x 64 pixel LCD display makes information easy to read
- Front panel programming and also via PC software
- Soft touch membrane keypad and five key menu navigation
- Remote communications via RS232, RS485 and ethernet.
- Event logging (50) showing date and time
- Multiple date and time engine exercise mode and maintenance scheduler
- Engine block heater control.

- Controls; stop, manuel, auto, test, start, mute lamb test/transfer to generator, transfer to mains, menu navigation.

APD 1650 M

ENGINE Engine speed Oil pressure Coolant temperature Run time Battery volts Engine maintenance due GENERATOR Voltage (L-L, L-N) Current (L1-L2-L3) Frequency Earth current KW Pf KVAr Phase sequence MAINS Voltage (L-L, L-N) Charge failure Battery under voltage Fail to stop Low fuel level (opt.) KW ver load	Instruments
Oil pressureCoolant temperatureRun time Battery voltsEngine maintenance dueGENERATORVoltage (L-L, L-N)Current (L1-L2-L3)FrequencyEarth currentKWPfKVArKVArPhase sequenceMAINSVoltage (L-L, L-N)FrequencyBattery under voltageFait to stopLow fuel level (opt.)KW over load	ENGINE
Coolant temperatureRun time Battery voltsEngine maintenance dueGENERATORVoltage (L-1, L-N)Current (L1-L2-L3)FrequencyEarth currentKWPfKVArKVArVoltage (L-1, L-N)PrequenceMAINSVoltage (L-1, L-N)FrequencyBattery under voltageFil to stopLow fuel level (opt.)KW over load	Engine speed
Run time Battery voltsEngine maintenance dueGENERATORVoltage (L-L, L-N)Current (L1-L2-L3)FrequencyEarth currentKWPfKVArKVh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyBattery under voltageGharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	Oil pressure
Engine maintenance dueGENERATORVoltage (L-L, L-N)Current (L1-L2-L3)FrequencyEarth currentKWPfKVArKVh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	Coolant temperature
GENERATORVoltage (L-L, L-N)Current (L1-L2-L3)FrequencyEarth currentKWPfKVArKWh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	Run time Battery volts
Voltage (L-L, L-N)Current (L1-L2-L3)FrequencyEarth currentKWPfKVArKWh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	Engine maintenance due
Current (L1-L2-L3)FrequencyEarth currentKWPfkVArkVAn, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyKARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	GENERATOR
FrequencyEarth currentkWPfkVArkVAn, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	Voltage (L-L, L-N)
Earth currentKWPfKVArKWh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGBattery under voltageFail to stopLow fuel level (opt.)KW over load	Current (L1-L2-L3)
kWPfkVArkWh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGBattery under voltageFail to stopLow fuel level (opt.)KW over load	Frequency
PfkVArkWh, kVAh, kVAhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	Earth current
kVArkWh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)kW over load	kW
kWh, kVAh, kVArhPhase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)kW over load	Pf
Phase sequenceMAINSVoltage (L-L, L-N)FrequencyWARNINGCharge failureBattery under voltageFail to stopLow fuel level (opt.)KW over load	kVAr
MAINS Voltage (L-L, L-N) Frequency WARNING Charge failure Battery under voltage Fail to stop Low fuel level (opt.) KW over load	kWh, kVAh, kVArh
Voltage (L-L, L-N) Frequency WARNING Charge failure Battery under voltage Fail to stop Low fuel level (opt.)	Phase sequence
Frequency WARNING Charge failure Battery under voltage Fail to stop Low fuel level (opt.) KW over load	MAINS
WARNING Charge failure Battery under voltage Fail to stop Low fuel level (opt.) KW over load	Voltage (L-L, L-N)
Charge failure Battery under voltage Fail to stop Low fuel level (opt.) kW over load	Frequency
Battery under voltage Fail to stop Low fuel level (opt.) kW over load	WARNING
Fail to stop Low fuel level (opt.) kW over load	Charge failure
Low fuel level (opt.) kW over load	Battery under voltage
kW over load	Fail to stop
	Low fuel level (opt.)
Negative phase sequence	kW over load
	Negative phase sequence

Loss of speed signal

PRE-ALARMS

Low oil pressure

High engine temperature

Low engine temperature

Over /Under speed

Under/over generator frequency

Under/over generator voltage

ECU warning

SHUT DOWNS

Fail to start

Emergency stop

Low oil pressure

High engine temperature

Low coolant level

Over /Under speed

Under/over generator frequency

Under/over generator voltage

Oil pressure sensor open

Phase rotation

ELECTRICAL TRIP

Earth fault

kW over load

Generator over current

Negative phase sequence

Options

High oil temperature shut down

Low fuel level shut down

Low fuel level alarm

High fuel level alarm

EXPANSION MODULES

Editional LED module (2548)

Expension relay module (2157)

Expansion input module (2130)

Standards

Elecrical Safety / EMC compatibility

BS EN 60950 Electrical business equipment

BS EN 61000-6-2 EMC immunity standard

BS EN 61000-6-4 EMC emission standard

STATIC BATTERY CHARGER

AKSA POWER GENERATION

Battery charger is manufactured with switching-mode and SMD technology and it has high efficincy.

Battery charger models' output V-I characteristic is very close to square

2405 has fully output shot circuit protection and it can be used as a current source.

2405 charger has high efficiency, long life, low failure rate, light weight and low heat radiated in accordance with linear alternatives.

APD 1650 M

The charger is fitted with a protection diode across the output.

Charge fail output is available.

Connect charge fail relay coil between positive output and CF output.

Input: 196-264V.

Output: 27,6V 5A or 13,8V 5A.

STANDARD SPECIFICATIONS

- Water cooled diesel engine
- Radiator with mechanical fan
- Protective grille for rotating and hot parts
- Electric starter and charge alternator
- Starting battery (with lead acid) including rack and cables
- Engine coolant heater
- Steel base frame and anti-vibration isolators
- Spare external fuel tank (open set)
- Flexible fuel connection hoses
- Single bearing, class H alternator
- Industrial exhaust silencer and steel bellows supplied separately
- Static battery charger
- Manual for application and installation
- Generators Sets' voltage and frequency regulation comply with ISO 8528-5
- Generators Sets' can take 100% load at one step according to NFPA110

OPTIONAL EQUIPMENTS

ENGINE Fuel-Water Seperator Filter Oil heater ALTERNATOR Anti-Condensation Heater Main line circuit breaker CONTROL SYSTEM Automatic synchronising and power control system (multi gen-set Parallel) Paralel system with mains. Transition synchronization with mains

.



	-	
Remote relay output		
Alarm output relays		
Remote communication with	modem	
Earth fault, single set		
Charge Ammeter		
TRANSFER SWITCH		
Three or four pole contactor		
Three or four pole motor ope	arated circuit breaker	
OTHER ACCESSORIES		
Main Fuel Tank		
Automatic or manual fuel fill	ng system	
Manual oil drain pump		
Low and high fuel level alar	n	
Residential silencer		
Enclosure: weater protective	or sound attenuated	
Duct adapter (on radiator)		
Inlet and outlet motorised lo	uvers	
Inlet and outlet acoustic baf	les	
Tool kit for maintenance		
1500/3000 hours maintenan	ce kit	
Supplied with oil and coolan	t - 30 °C	
AKSA CERTIFICATES		
- TS ISO 8528		
- TS ISO 9001-2008		

- CE
- SZUTEST
- 2000/14/EC